



ACCURATE & EASY TO USE

Discover a wide selections of our
sound measurement equipments according to your
sound measurement needs

POFM 01

OPTICAL FIBER
MICROPHONE
SYSTEM

www.placidinstruments.com



PLACID INSTRUMENTS BV


Newtonlaan 115 Office No. 2.21 3584 BH UTRECHT, THE NETHERLANDS

Phone +31 302106021

email info@placidinstruments.com

website www.placidinstruments.com

PLACID OPTICAL FIBER MICROPHONE SYSTEM **POFM 01**





PLACID INSTRUMENTS BV

Newtonlaan 115 Office No. 2.21 3584 BH UTRECHT, THE NETHERLANDS

Phone +31 302106021

email info@placidinstruments.com

website www.placidinstruments.com

PLACID OPTICAL FIBER MICROPHONE SYSTEM

POFM 01



OVERVIEW

The PLACID POFM01 Fiber optic microphone system consists of a fiber optic microphone, transmission fiber, photoelectric conditioning module, audio cable, power supply. optical fiber microphone system

Its audio output is based on analog output of standard audio cables, without the need for additional preamplifiers. Each fiber optic microphone has been individually calibrated during the production process to achieve consistent performance.

The basic working principle of fiber optic sensors is to use light emitting diodes (LEDs) as the light source and incident it onto a metal coated vibration diaphragm through the optical fiber. When the sound signal causes the diaphragm to vibrate, the incident light is modulated by the diaphragm vibration and reflected out. The receiving fiber receives reflected light, which can be demodulated and restored to an acoustic signal.



PLACID INSTRUMENTS BV

Newtonlaan 115 Office No. 2.21 3584 BH UTRECHT, THE NETHERLANDS

Phone +31 302106021

email info@placidinstruments.com


website www.placidinstruments.com

PLACID OPTICAL FIBER MICROPHONE SYSTEM | POFM 01

FEATURES

INTEGRATING OPTICAL AND ACOUSTIC CHARACTERISTICS:

- High sensitivity
- Compact structure
- Front end passive
- Anti electromagnetic/radio frequency interference
- Passive sensitive components
- Wide frequency response
- Standard analog output
- High reliability and environmental stability
- Fiber optic connection without signal loss
- Real time listening via 3.5 mm jack output in DAQ





PLACID INSTRUMENTS BV

Newtonlaan 115 Office No. 2.21 3584 BH UTRECHT, THE NETHERLANDS

Phone +31 302106021

email info@placidinstruments.com


website www.placidinstruments.com

PLACID OPTICAL FIBER MICROPHONE SYSTEM | POFM 01

SPECIFICATION POFM01



| | |
|-------------------------------|--------------|
| Sensitivity | 200 mV/Pa |
| Frequency Range | 3.15 – 6K Hz |
| Upper Limit for Dynamic Range | 114 dB |
| Length | 1 – 200 m |
| Type | Interference |
| Selfnoise | 30 dB |





PLACID INSTRUMENTS BV

Newtonlaan 115 Office No. 2.21 3584 BH UTRECHT, THE NETHERLANDS

Phone +31 302106021

email info@placidinstruments.com

website www.placidinstruments.com

APPLICATION

Industrial equipment monitoring

High voltage electrical equipment

High explosive areas


Magnetic resonance imaging
environment

High electromagnetic interference
and radio frequency interference
environment

Petrochemical industry and nuclear
industry

Stage broadcast recording

Electromagnetic Compatibility Testing
Laboratory





Placid Instruments BV

Newtonlaan 115, Office No. 2.21

3584 BH UTRECHT

THE NETHERLANDS

Phone landline : +31 302106021

Email : info@placidinstruments.com

www.placidinstruments.com

ASK US!
HERE

